

# **AWNING HUB XTM**

# **Instruction Manual**



# PARTS LIST

PARTS LIST:	
DESCRIPTION	QTY
Tent	1
Awning Poles	2
Steel Pegs	20
Carry Bag	1
Guy Ropes	2
Straps	2



Awning Pole



Tent

Steel Peg



Guy Rope



Carry Bag


### SET UP INSTRUCTIONS

Step 1

Ensure the ground is free from sharp objects, unfasten the tent and spread it out on the ground. Then peg down the floor.




Step 2 Slide the roof pole out from both sides until you hear a "click" sound.



#### Step 3

Stretch all four leg poles until you hear a "click" sound. The poles are now fully extended.



#### Step 4 Fasten all floor adjustable webbings and peg down.



#### Step 5

Fix the roof fly by using guy ropes and peg out away from the tent.



#### Step 6


To assemble the awning use the steel poles and guy ropes provided. Peg down the guy ropes to secure the poles.



# ADDITIONAL INSTRUCTIONS FOR FITTING TO AN XTM AWNING


#### Step 1

The awning with channel slot (as picture) can be attached to awning hub. There is a keder connector above the front door.



#### Step 2

First take the keder connector off awning hub, and insert the keder into channel slot.



#### Step 3

Then zip the zipper of keder connector and awning hub, attach all the adjustable webbing straps to awning poles.



PLU: 616753 CODE: CL-AHUB Manufactured and Packaged for SRG PTY LTD ABN 23 113 230 050 6 Coulthards Avenue Strathpine QLD 4500 Australia MADE IN CHINA