

USER MANUAL

How to install

1. Ensure surface is dry and clean.
2. Take the protection cover off the suction plate.
3. Apply suction plate to flat smooth surface.
4. Press the suction cup firmly to squeeze the air out.
5. Once you have installed wait 2-3 minutes before use.

Attention: Do not use on cracked surfaces.

How to detach

1. From the bottom of suction plate, use a plastic card to lift the suction plate up slowly and detach carefully.

CAUTION

Do not exceed weight rating when in use.

For reuse, clean suction plate thoroughly with running water and use once dry.

Keep out of reach of children.

Manufactured & packaged for
SRGS PTY LTD
ABN 23 113 230 050
6 Coulthards Avenue
Strathpine QLD 4500, Australia
MADE IN CHINA