### 6.5 ADJUSTABLE 12 V CARAVAN/MARINE FAN

## **TVD-FAN3**

# 2 Speed Marine Fan




**INSTRUCTION MANUAL** 

#### WARNING:

- Do not position too close to any objects that may be drawn into the blades and stop the airflow
- · Do not use outdoors
- Do not use on wet surfaces or immerse in water
- Never allow water to drip into motor housing
- Do not use if wires become frayed or brittle
- Do not use near fireplaces, furnaces, stoves or high temperature heat
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.

#### **OVERVIEW:**



Grip handle to adjust position of fan

2 speeds Push-button control

Unlock to adjust vertical position Lock to hold fan in place

Loosen stand-nut to Swivel fan position from side to side

DC12V plug with LED indicator

#### INSTALLATION:

- · Require a 3amp fused circuit.
- Use two supplied screws to attach the fan base.
- Plug it into a DC12V socket.

#### **OPERATING INSTRUCTIONS:**

The blade must be clear of any obstructions that would cause the blade to jam. Secure locking cam in position before turning on. Press button on the face of fan once to turn on. Press button again to adjust speed levels and to turn the fan off.

#### CARE & MAINTENANCE:

The fan requires very little maintenance. By following the instructions within this manual, the fan will operate problem-free for years.

Turn power off to clean. A vacuum can be used to clear the fan of any dust build-up and a dry cloth my be used to wipe the surface. Do not use gasoline, thinners or other harsh chemicals to clean fan.

#### SPECIFICATIONS:

DC12V, 0.12amp (low speed), 0.23amp (high speed)