

KICKASS[®]

CAMPING FAN WITH LED LIGHT AND POWER BANK

USER MANUAL



KA5VCAMPFAN

PRODUCT SPECIFICATIONS

BATTERY	3.7V/20000mAh
INPUT	5V/2A Max
CHARGE OUTPUT	USB C 5V/2A Max
CHARGE OUTPUT	USB A 5V/2A Max
CHARGE TIME	8-10 hours
WORKING TIME	15- 18 hours
PRODUCT DIMENSIONS	220 x 240 x 110mm

WARNING

- The remote control contains 1 x CR 2025 lithium coin cell battery. This is dangerous if swallowed.
- Keep the coin cell battery out of reach of children.

⚠ WARNING

KEEP OUT OF REACH OF CHILDREN

Swallowing can lead to chemical burns, perforation of soft tissues, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.



THINGS YOU SHOULD KNOW

- Working time for this fan depends on whether it is run continuously or intermittently. Intermittent operation extends the running time of the battery.
- Do not attempt to disassemble or replace the battery or batteries.
- Children must always be supervised when around this fan.

CHECKING REMAINING BATTERY CAPACITY

- Do not alter or remove the factory plates or identification labels.
- Do not disassemble the device.

LED ● ON / ○ OFF	REMAINING CAPACITY
● ○ ○ ○	Less than 25%
● ● ○ ○	25% to 50%
● ● ● ○	50% to 75%
● ● ● ●	75% to 100%

CLEANING INSTRUCTIONS

- Ensure the unit is switched off and disconnected from a power source before cleaning.
- Clean the outside of the fan with a damp cloth only. Avoid excessive water.
- Do not use any abrasive cleaners or harsh chemicals, as these can damage the fan.
- Ensure all components are completely dry before storing the fan.

Kickass is a registered trademark of
Kickass Products Pty Ltd

Designed & imported by
Kickass Products Pty Ltd
39 Iris Place, Acacia Ridge, QLD 4110
Australia



MADE IN CHINA