PADDED CAMPING STRETCHER


Please read this user manual carefully before use and please keep it for future reference.



PLU: 691365

STRETCHER INSTRUCTION SHEET

TO SET UP-



STEP 1: Select a smooth level site and stand the frame on its feet



STEP 2:

Grasp the corner legs and slowly unfold the frame, completely expanding the stretcher's surface until it is level.



STEP 3:

Put hands on left and right poles of footrest, press down both poles at the same time until you feel the plastic "snap" as you guide the connector into place.



DONE

TO TAKE DOWN:

STEP 1: Standing on one side, locate the plastic connector in the middle of the lock bar pole. Then press down on the plastic connector.

Repeat on the other side.

STEP 2: Raise both side pole up, beginning at opposite ends, slowly fold the frame up, raising its ends toward the middle.

STEP 3: Place unit into its storage bag. Zip to close.





▲ WARNING:

Maximum Comfort Stretcher Weight Capacity: 120kg

EXERT CARE WHEN ASSEMBLING/DISASSEMBLING FRAME SO THAT FINGERS ARE NOT PINCHED. EXCEEDING MAXIMUM SURFACE WEIGHT CAPACITY LIMIT MAY CAUSE PERSONAL INJURY AND/OR DAMAGE TO PRODUCT: USER MUST ENSURE WEIGHT IS EVENLY DISTRIBUTED OVER SURFACE AREA. TO AVOID INJURY AND PRODUCT FAILURE, ANY USER SHOULD CAREFULLY MONITOR SURFACE AREA. THIS PRODUCT IS NOT A TOY. THIS PRODUCT IS NOT INTENDED FOR USE BY CHILDREN WITHOUT ADULT SUPFACE, PREFERABLY AT GROUND LEVEL. THIS PRODUCT HAS BEEN DESIGNED FOR NORMAL AND CUSTOMARY USAGE; ANY OTHER USE MAY CAUSE SERIOUS PERSONAL INJURY OR PRODUCT FAILURE.