

User Manual



Solar Outdoor Powerbank

PB-NRG20K-344

WHAT'S IN THE BOX:

- Powerbank
- User manual
- USB-C to USB-C charging cable

OVERVIEW



i A USB charger is required to charge the powerbank. This can be a wall charger, a car USB charger or any USB powered port.

Micro USB port (IN)

For charging the powerbank.

USB-A ports (OUT)

For charging your other devices.

USB-C port (IN/OUT)

For charging the powerbank and your other devices.

Solar panel

Solar charging indicator (green)
Remaining battery capacity indicators (blue)

Power button

Press to see remaining battery capacity.
Press and hold to turn on the flashlights. Then press to change flashing modes and turn off the lights.

SPECIFICATIONS

- **Capacity:** 20,000mAh (74Wh)
- **Power - input:**
 - USB-C: 5V/3A, 9V/2A, 12V/2.5A
 - Micro USB: 5V/2A
- **Power - output:**
 - USB-C: 5V/3A, 9V/2.22A, 12V/1.67A
 - USB-A: 5V/3A, 9V/2A, 12V/1.5A
 - Total (USB-C + USB-A / USB-A + USB-A / USB-C + USB-A + USB-A): 22.5W
- **IP rating:** IP54
- **Operating temperature range:** 5°C to 40°C
- **Dimensions (L×W×D):** 165×87×24mm
- **Weight:** 420g

SAFETY PRECAUTIONS

- Unplug the cable when your device is fully charged. Also, when the power bank is full, disconnect the cables.
- Use the powerbank only for charging electronic devices.
- Disconnect when not using it.
- Keep away from extreme temperatures.
- Do not submerge in water.
- Protect from physical damage.
- Use a soft, dry cloth for gentle cleaning. If necessary, dampen it slightly with water. Avoid harsh chemicals.
- Don't take apart or change the power bank.
- Follow local laws for disposing and recycling batteries; don't toss it in regular bins.