

Weber® Q™ +

(Q2600N+)



Expand your cooking possibilities with the Weber Q+ barbecue. In addition to grilling, roasting and baking, the additional + burner allows you to cook low and slow and sear on high heat - for the ultimate steak. You're only limited by your imagination!

Number of burners	2 (Q burner, + burner)
Fuel	LPG or Natural Gas



KEY FEATURES AND BENEFITS

Wide temperature range

The + burner expands your cooking possibilities – bake, roast, grill, sear on high and barbecue low and slow.

Large cooking area

Large cooking area – can grill up to 12 burgers at one time.

Porcelain-enamelled cooking grills

Porcelain-enamelled cast-iron cooking grills for great heat retention and even heat distribution.

High domed lid

High domed lid for large roasting capacity.

Front-facing grease tray

Easily accessible, front-facing grease tray helps make cleaning quick and simple.

Push button ignition

Push button piezo ignition for quick and convenient lighting.

Weber Connect compatible

Compatible with Weber Connect Smart Barbecuing Hub for step-by-step barbecuing assistance.

Front-facing control dials

Front facing control dials make adjusting barbecue settings simple.

WHAT'S IN THE BOX

Barbecue assembly
Hose and regulator (LPG: 1 m with type 27 fitting, NG: 2 m with bayonet fitting)
Owner's Manual
QR code link to Digital User & Recipe Guide

SPECIFICATIONS



@weberBBQAusNz

www.weber.com



Cooking Accessories



Weber Q Full hotplate

Transform your entire grilling surface into a full size flat plate in seconds with the full hotplate. Perfect for breakfast cook ups, smash burger lunches or fajita nights.



Weber Q Starter pack

Explore a range of cooking possibilities with this starter pack. Contains a roasting trivet and 10 convection trays, a pizza stone with pizza tray and a frying pan with detachable handle.



Casserole dish

Take your barbecue cooking to another level with the Q ware casserole dish. Keep the heat and smells out of the kitchen by braising or stewing curries and casseroles, or baking desserts or cakes - all on your barbecue!



Premium cart

Show off your Baby Q or Q series barbecue with this sleek and stylish premium cart. It securely lifts your barbecue to the perfect cooking height.

Cleaning and Care Accessories



Grill brush - 30 cm

This three-sided grill brush is made to remove grease and debris from cooking grills of all sizes. The handle design provides a secure grip when brushing off stuck-on food or cleaning tight spaces.



Cookbox scraper

Keep your barbecue cookbox free of grease build-up and food scraps.



Weber Q Cleaner

Keep your new Weber Q looking its best. It's unique formula will remove grease, fat and smoke stains, to keep your barbecue clean.



Premium BBQ and cart cover

Keep your barbecue and cart in top shape and protect it from the harsh outdoor elements with this full-length Baby Q and Q series premium barbecue and cart cover.



YOUR LOCAL STORE DETAILS



@weberBBQAusNz

www.weber.com

